



기능설정순서 및 설정 메뉴
Configuration Menu
功能設定順序及設定菜單



MODE	Description	Range	Default	MODE	Description	Range	Default	MODE	Description	Range	Default
P4000	암호설정 Password setting	000-999 (000 for no password setting)	000	5C 4	기동 온도 설정 Start threshold (multiple of oc)	0F, 2-8 > 0C x 240A	4	P4100	PT100 4선제비 온도 표시(설정가능) PT100 4-wire temperature display (unable to be set)	0-200A	0
P4300	3상전압 또는 단상전압 3-phase or single phase	3ph, 1ph	3ph	5R 4	온도 측정 수칙 Temperature measurement rule	0F, 1.5-5 > 0C x 240A	4	420 3	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P4400	시간설정 Time setting	no, de, in, th (none, define, inverse, thermal inverse)	de	5L 5	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 4	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P4500	기본 CT 비례 설정 외부CT 비례 Basic CT ratio setting external CT ratio	Non, 2L, 5L (none, 2L, 5L)	non	5L 6	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 5	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P4600	시스템 기본주파수 System fundamental frequency	50, 60	60	5L 7	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 6	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P4700	Fail Safe 기능 선택 Fail Safe function selection	On, off	off	5L 8	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 7	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P4800	역상 선택 / 방법 Reverse phase selection	On, off	off	5L 9	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 8	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P4900	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 10	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 9	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5000	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 11	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 10	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5100	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 12	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 11	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5200	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 13	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 12	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5300	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 14	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 13	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5400	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 15	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 14	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5500	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 16	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 15	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5600	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 17	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 16	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5700	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 18	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 17	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5800	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 19	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 18	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P5900	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 20	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 19	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0
P6000	과전류 과열 감지 Over current / overheating detection	On, off	off	5L 21	온도 측정 수칙 Temperature measurement rule	0-2-10	5	420 20	4-20mA Analog input data 표시(설정가능) 4-20mA Analog input data display (unable to be set)	0-200A	0

